

Owens Corning™ Basement Finishing System™

Panel Removal & Re-installation Procedure

- Begin by removing any electrical switch or plug covers.
- Look at the cove trim at the top and the base trim at the bottom of the panels. One or both need to be removed. Begin by finding one end of the trim and with a twisting motion pull the trim out of the lineal. Mark the backside of the trim so you will be able to re-install back into the correct location.
- After removing the horizontal trim, remove the vertical trim on both sides of the panel.
- Remove the panel by hooking your finger around the back of the panel at the corners as shown and carefully pulling out. Use caution not to damage the edges or corners of the panel when moving it around. If removing more than one panel, be sure to mark the backside of the panel so you will be able to re-install back into the correct location.
- Re-installation is the reverse of the removal procedure. Re-install the panels, then the trim, and electrical covers making sure you are using the correct parts in the correct locations. Push the trim into the lineals by hand or use a white rubber mallet to tap the trim into place.

